

Oil Bath (Large Capacity)

Model BOA201 / 311

Instruction Manual

- First Edition -

Thank you for purchasing "Constant Temperature Oil Bath, BOA201/311" of Yamato Scientific Co., Ltd.

•For proper equipment operation, please read and become thoroughly familiar with this instruction manual before use. Always keep equipment documentation safe and close at hand for convenient future reference.

WARNING: Read instruction manual warnings and cautions carefully and completely before proceeding.

Yamato Scientific Co. Ltd.

Printed on recycled paper

TABLE OF CONTENTS

1. SAFETY PRECAUTIONS	1
Explanation of Symbols	1
Symbol Glossary	2
WARNING / CAUTION	3
Residual Risk Map	5
List of Residual Risks	6
2. COMPONENT NAMES AND FUNCTIONS	9
Main Unit (BOA201/311)	9
Control panel	10
Display Characters	11
3. PRE-OPERATION PROCEDURES	12
Installation Precautions	12
4. PRE-OPERATIVE PREPARATIONS	15
Operation Modes and Functions	15
Mode & Function Flow	16
PRE-OPERATIVE PREPARATIONS	17
Overheat Prevention Device Setup	19
5. OPERATION PROCEDURES	20
Fixed Temperature Operation	20
Independent overheat prevention device function	22
Emergency stop switch function	22
Other Functions: Calibration Offset	23
Other Functions: Keypad Lock	24
Other Functions: Auto-resume Function	25
Various output terminal functions	26
How to set the temperature output terminal output range	28
Overview of external communication terminals	29
Communication settings	30
Remote communication parameter setting (option)	30
Communication procedure	33
Communication message type	34
Configuration of Toho protocol request message (sending from host computer to this	;
product)	35

Code description for the Toho protocol	37
Precautions for Toho protocol communication	
Toho protocol read communication example	40
Modbus-RTU request message configuration (sending from host computer to this	
product)	42
Modbus-RTU code description	44
Modbus-ASCII request message configuration (sending from host computer to this product)	48
Modbus-ASCII code description	50
Modbus-ASCII communication notes	52
Modbus-ASCII read communication example	53
Precautions for setting by communication	55
Operation setting command	55
Submenu command	56
Monitor command	56
Communication parameter command	58
ASCII code table	59
Multi-drop connection example	60
6. HANDLING PRECAUTIONS	61
Warnings and Cautions	61
7. MAINTENANCE PROCEDURES	64
Precautions before Inspection	64
Precautions in Daily Maintenance	64
Maintenance and Inspection	64
Cleaning the intake filter	65
8. EXTENDED STORAGE AND DISPOSAL.	66
Extended storage	66
Disposal Considerations	66
9. TROUBLESHOOTING	67
Reading Error Codes	67
Troubleshooting Guide	68
10. SERVICE & REPAIR	69
Requests for Repair	69
11. SPECIFICATIONS	70
12. LIST OF HAZARDOUS SUBSTANCES	72

3. STANDARD INSTALLATION MANUAL73

Explanation of Symbols

A Word Regarding Symbols

Various symbols are provided throughout this text and on equipment to ensure safe operation. Failure to comprehend the operational hazards and risks associated with these symbols may lead to adverse results as explained below. Become thoroughly familiar with all symbols and their meanings by carefully reading the following text regarding symbols before proceeding



Symbol Glossary

WARNING / CAUTION





Danger!: High Voltage



Caution: Water

Only



Caution: Shock

Hazard!



Danger!: High Temperature



Caution: Burn Hazard!



Danger!: Moving Parts



Caution: Do Not Heat Without Water!



Danger!: Blast Hazard



Caution: May Leak Water!



Caution: Toxic Chemicals







General Network

No Open Flame





Do Not Disassemble

Do Not Touch





General Action Required



Connect Ground Wire



Level Installation



Disconnect Power



Inspect Regularly

WARNING / CAUTION

\land WARNING

Install in a location free of flammables and explosives.

Never install or operate unit in a flammable or explosive gas atmosphere. This unit is NOT fire or blast resistant. Simply switching earth leakage breaker (ELB) "ON" or "OFF" can produce a spark, which can then be relayed during operation, causing fire or explosion when near flammable or explosive fluids, chemicals or gases/fumes. See "LIST OF HAZARDOUS SUBSTANCES" (P.) for information on flammable and explosive gases.



Ground wire MUST be connected properly

If there is no ground terminal, contact original dealer of purchase for location-specific electrical requirements. Securely connect to a distribution board. No power plugs or connectors of any kind are included with this unit. When using a power plug, use a plug that meets the voltage and electrical capacity.



Core color	Wiring on distribution board
White	Neutral
Black	Live
Green	Ground

Never connect ground wire to gas lines, water pipes, telephone grounding lines, or lightning conductor rods. Malfunction, electric shock, fire, or other accident may result.

Turn OFF (o) ELB immediately when an abnormality occurs.

If unit begins emitting smoke or abnormal odors for reasons unknown, turn OFF (\circ) ELB immediately, disconnect power cable from power supply, and contact original dealer of purchase for assistance. Continuing to operate without addressing abnormalities may cause fire or electric shock, resulting in serious injury or death. Never attempt to disassemble or repair unit. Repairs should always be performed by a certified technician.

DO NOT disassemble or modify equipment

Never attempt to disassemble or modify unit. Doing so may cause malfunction, fire, electric shock, or personal injury. Note that any malfunction resulting from unauthorized modifications or customizations to unit will void the warranty.

WARNING / CAUTION



Handle power cable with care.

- Do not operate unit with power cable bundled or tangled. Operating unit with the power cable bundled or otherwise tangled, may cause power cable to overheat and/or catch fire.
- Do not modifiy, bend, forcibly twist or pull on power cable. Fire or electric shock may result.
- Do not risk damage to power cable by positioning it under desks or chairs, or by allowing it to be pinched in between objects. Fire or electric shock may result.
- Do not place power cable near kerosene/electric heaters or other heat-generating devices. Doing so may cause power cable insulation to overheat, melt and/or catch fire, which may result in electric shock.
- Turn off (o) ELB immediately and disconnect from facility terminal or outlet, if power cable becomes partially severed or damaged in any way. Contact original dealer of purchase for information about replacing power cable. Continuing to operate without addressing abnormalities may cause fire or electric shock, resulting in serious injury or death.

-Connect the power cord to the appropriate distribution board.



DO NOT touch hot surfaces.

Do not touch the vicinity of the oil bath during operation or immediately after operation. Burn injury may result.

DO NOT climb or place any objects on top of equipment.

Personal injury or equipment malfunction may result. Do not place any products other than those specified as options on top of unit. Personal injury or equipment malfunction may result.

Ω

DO NOT operate equipment during thunderstorms

In the event of a thunderstorm, turn OFF (\circ) ELB and disconnect power cable immediately. A direct lightning strike may cause equipment damage, fire or electric shock, resulting in serious injury or death.

0

Turn OFF () ELB in case of power failure.

Operation stops when power failures occur. For added safety however, turn OFF (\circ) ELB in the event of a power failure.

Residual Risk Map

These figures indicate positions of caution labels.

The numbers shown in the figure indicate the numbers listed in the "List of Residual Risks" in this manual.

For details of individual residual risks, see the List of Residual Risks.



*Contact original dealer of purchase if the nameplates and caution labels have come off, or become illegible. New nameplates are available at cost.

List of Residual Risks

List of residual risks (instructions for risk avoidance)

This list summarizes residual risks to avoid personal injuries or damages to properties during or related to the use of equipment.

Be sure to fully understand or receive instructions on how to use, maintain and inspect equipment before starting operation.

	Loading/Installation				
No.	Degree of risks	Risk description	Protective measures taken by the user	Relevant page	
1	CAUTION	Injury	Always use cargo-handling equipment to move or install unit. Transport unit with sufficient number of people and an appropriate work method when carrying out manually.	P.13	
2	WARNING	Fire/Electric shock	Choose an appropriate installation site.	P.12	
3	CAUTION	Injury	Install unit on a level surface.	P.13	
4	CAUTION	Injury	Take appropriate safety measures when installing.	P.13	
5	WARNING	Fire	Install equipment in a well-ventilated place	P.14	
6	WARNING	Fire/Electric shock	Install in a dry location.	P.14	
7	WARNING	Explosion/fire	Install in a location free of flammables and explosives.	P.3	
8	WARNING	Fire/Electric shock	Always connect power cable to appropriate facility outlet or terminal.	P.13	
9	WARNING	Fire/Electric shock	Handle power cable with care.	P.4	
10	WARNING	Fire/Electric shock	Ground wire MUST be connected properly	P.3	
11	WARNING	Fire/Electric shock	DO NOT disassemble or modify equipment.	P.3	
12	CAUTION	Injury/Fire	Implement proper fire extinguishing and ventilation measures.	P.14	

List of Residual Risks

	Use				
No.	Degree of risks	Risk description	Protective measures taken by the user	Relevant page	
13	WARNING	Explosion/fire	DO NOT process explosive or flammable substances	P.61	
14	WARNING	Fire/Burn	Never move unit while in operation.	P.17	
15	WARNING	Fire/Electric shock	Turn OFF (○) ELB immediately when an abnormality occurs.	P.3	
16	WARNING	Fire/Electric shock Burn	Take care not to drop test samples or objects into the inside unit.	P.61	
17	CAUTION	Fire	In the event of a power failure with Auto-resume mode "ON", unit automatically reverts to status just before power loss and begin operation once again from that point. Be sure to confirm the state of unit when the power is supplied again.	P.62	
18	CAUTION	Burn	Do not operate the drain valve until the oil temperature drops below 45 ° C.	P.17	
19	WARNING	Burn	DO NOT touch hot surfaces	P.4	
20	WARNING	Fire	Never operate unmanned at high temperatures as it is dangerous.	P.17	
21	WARNING	Injury	DO NOT climb or place any objects on top of equipment.	P.4	
22	WARNING	Fire	DO NOT operate equipment during thunderstorms	P.4	
23	CAUTION	Burn Injury	ALWAYS run equipment within specified temperature range.	P.62	
24	WARNING	Burn	Pay attention to internal temperature after operation.	P.61	
25	WARNING	Fire/Electric shock	Carefully handle test samples.	P.61	
26	WARNING	Injury/Fire	The media that can be used with this product are water (ion-exchanged water, distilled water) and silicone oil.	P.17	
27	WARNING	Burn Injury, fire	Since silicone oil has a large thermal expansion, the maximum supply amount should be up to 28 ^ℓ .	P.18	
28	WARNING	Fire	Set the overheat prevention activation temperature.	P.61	

List of Residual Risks

	Daily inspection/maintenance				
No.	Degree of risks	Risk description	Protective measures taken by the user	Relevant page	
29	WARNING	Fire/Electri c shock	Be sure to disconnect power cable before daily inspection and maintenance.	P.64	
30	WARNING	Burn	Perform inspections and maintenance when unit is at room temperature.	P.64	
31	WARNING	Fire/Electri c shock	DO NOT disassemble or modify equipment.	P.3	

	Extended storage/disposal				
No.	Degree of risks	Risk description	Protective measures taken by the user	Relevant page	
32	WARNING	Fire/Electri c shock	Turn OFF (○) ELB and disconnect power cable from facility outlet or terminal.	P.66	
33	CAUTION	Injury	Do not leave unit in a location where children may have access	P.66	

2. COMPONENT NAMES AND FUNCTIONS



2. COMPONENT NAMES AND FUNCTIONS

Control panel



No	Panel Item	Description
1	RUN/STOP Key	Press one second to start or stop a constant temperature
	-	operation.
2	▼ ▲ keys	Press to increase or decrease the setting value.
3	ENTER key	Press to finalize setting.
4	FIXED TEMP Key.	It is a key to set the constant temperature for fixed value operation.
5	SUB MENU Key	Press and hold for two seconds to enter Submenu. Overheat Prevention Device Setup, Calibration offset, Keypad lock, Auto-resume mode select, Temperature output Scaling setting, Remote comm parameter setting (option) may be set.
6	HEATER lamp	Illuminates when heater is on and drawing power.
$\overline{\mathcal{O}}$	ALARM lamp	Illuminates when an error occurs.
8	FIXED TEMP. Lamp	Illuminates while fixed temperature operation is in progress. Flashes while setting.
9	Temperature reading display	Shows current chamber temperature, setting characters, and error codes.
10	Temperature setting display	Displays the set temperature, Fix indicating the constant temperature operation mode, etc.
1	Overheat prevention display	Shows overheat prevention temperature setting
12	Communication lamp	Lights when the remote operation mode is set by communication, and blinks synchronously during communication.

2. COMPONENT NAMES AND FUNCTIONS

Display Characters

All characters displayed when making settings and during operation are defined as follows:

Character	Letters	Panel Item	Purpose
F, 11	Fix	Fixed temperature operation	Appears during Fixed temperature operation
55	Sv	Temperature setting	Appears while entering temperature settings for Fixed temperature operation.
<u>o</u> X	οН	Overheat prevention	Appears while setting activation temperature for overheat prevention device See "Overheat Prevention Device Setup" (P.19)
<u>c</u> RL	cAL	Calibration Offset function	Appears while entering offset temperature values See "Other Functions: Calibration Offset" (P.23)
Loch	Lock	Keypad lock	Appears while setting Keypad lock function See "Other Functions: Keypad Lock" (P.24)
Pon	Pon	Auto-resume mode select	Appears while setting Auto-resume function See "Other Functions: Auto-resume Function" (P.25)
<u></u>	tr	Temperature output scaling settings	Displayed when the temperature output scaling of the temperature output terminal is set. P.28 Refer to "How to set the temperature output terminal output range".
ErL	trL	Temperature output range Lower limit setting	Displayed when the lower limit of the temperature output range is set.
<u>Er</u> H	trH	Temperature output range Upper limit setting	Displayed when the upper limit of the temperature output range is set.
<u>coñ</u>	соМ	Remote communication parameter setting (option)	Displayed when setting communication parameters. P.30 Refer to "Communication parameter setting method"
Pre	Prt	Communication protocol setting	Displayed when setting the communication protocol
bcc	bcc	BCC check settings	Displayed when BCC check is set for communication.
<u>d8F</u>	dAt	Data length setting	Displayed when setting the communication data length
PRL	PAL	Parity setting	Displayed when setting communication parity.
526	SPb	Stop bit setting	Displayed when the communication stop bit is set.
685	bPS	Communication rate setting	Displayed when setting the communication speed.
Rdr	Adr	Avxiliary address setting	Displayed when setting the communication avxiliary address.
885	AWt	Response delay time setting	Displayed when setting the communication response delay time.
nod	Mod	Communication mode setting	Displayed when setting the communication mode.
[rEnt	rEMt	Remote display	Displayed when remote operation mode is selected by communication.

* For more information about key operation flow, see "Mode & Function Flow" (P.16)

Installation Precautions

Choose an appropriate installation site.

DO NOT install unit:

- where installation surface is not completely level, not even or not clean.
- where flammable or corrosive gases/fumes may be present.
- where external temperature will exceed 35 °C, will fall below 5 °C or will fluctuate largely.
- where liquid is assumed to splash on unit.
- A place with a large temperature difference.
- in excessively humid or dusty locations.
- in direct sunlight or outdoors.
- where there is constant vibration.
- in direct contact with the outside air.
- where power supply is erratic.
- where there is combustible material nearby.
- in the proximity of, particularly right bellow a fire alarm.
- where there is a risk of freezing or condensation.
- where exposed to a strong wind.

Install unit in a location with sufficient space, as specified below.



Install unit as stipulated by the ordinance of each prefecture.

Installation Precautions



Use cargo-handling equipment for transportation and installation.

Always use cargo-handling equipment to move or install unit. If it is necessary to transport unit by man power, be sure to carry out with more than two people, and an appropriate work method. Approx. weight: BOA201/311: 37kg

Install unit on a level surface.

Install unit on level and even surface. Failure to do so may cause abnormal vibrations or noise, possibly resulting in complications and/or malfunction.



Take appropriate safety measures when installing.

Implement appropriate safety measures for the installation environment. Unit may tip over or fall, causing injury or death during an earthquake or other unforeseen incident.



Always connect power cable to appropriate facility outlet or terminal.

Connect power cable to a suitable facility outlet or terminal, according to the electrical requirements.

Electrical requirements: BOA201:115 V AC single phase 50/60 Hz 18.5 A (ELB capacity 30 A) :220 V AC single phase 50/60 Hz 10A (ELB capacity 15 A) BOA311:115 V AC single phase 50/60 Hz 40.5A (ELB capacity 50 A) :220 V AC single phase 50/60 Hz 21A (ELB capacity 30 A)

Operational voltage range is ± 10 % of power rating, performance guarantee voltage range is ± 5 %, and frequency is ± 1 %.

* Check the line voltage on distribution board and properly evaluate whether to utilize a line being shared by other equipment. If unit is not activated by turning on ELB, take an appropriate course of action, such as connecting unit to a dedicated power source.

Extension cords may cause a drop in voltage, which may affect performance, resulting in failure to control or maintain proper temperature.

Installation Precautions

Observe wire color designation when connecting to facility terminal. Confirm that the facility main breaker is OFF Wiring on

before connecting the round terminals from the power cable. No power plugs or connectors of any kind are included with this unit. See table on the right and select a plug or terminal that meets the voltage and electrical capacity.

Core color	Wiring on distribution board
Black	Live
White	Neutral
Green	Ground

Install equipment in a well-ventilated place

Install unit so that side and rear panel vents are unobstructed and allowed to sufficiently diffuse heat.

Doing so may result in excessive temperatures inside the unit control panel, causing possible degraded CPU board performance, malfunction or fire. See "COMPONENT NAMES AND FUNCTIONS" (P.9) for location.



Install in a dry location.

Install unit where it will be free from liquid spray and other moisture. Failure to do so may result in control mechanisms becoming wet, causing malfunction, electrical shock and/or fire.



Implement proper fire extinguishing and ventilation measures.

The oily smoke and steam generated from heating silicon oil is flammable and may cause a fire hazard.

Silicon oil also emits harmful gases when heated to high temperatures. A ventilation hood must be installed above unit, with a fire extinguisher in close proximity.



Operation Modes and Functions

Operation modes for this unit are defined in the table below:



Operation functions for this unit are defined in the table below:

Description	Page
Automatic overheat prevention	
This function is set to automatically activate when chamber temperature exceeds the	
temperature setting by 6 °C.	
Unit will restart heater control when chamber temperature comes within temperature	_
setting +6 °C.	
(Error code is not displayed)	
Overheat prevention device (oH)	
Although this device uses the same power source, display, and keypad as the control	
panel, it has an independent temperature monitoring circuit and sensor.	
When chamber temperature exceeds temperature setting of the overheat prevention	P.19
device, power supply to heater is shut off and error lamp illuminates. Operation may be	
restarted when ELB is switched off (wait 5 seconds), then back on again. (manual reset)	
This setting can be made from Submenu.	
Calibration offset (cAL)	
Calibration offset function is to compensate for differences in the temperature reading (as	
taken by unit sensor) and actual chamber temperature (as taken manually with a	
thermograph).	P.23
Unit can be offset to either the positive or negative side of temperature line for entire	
temperature range of unit	
This setting can be made from Submenu.	
Overheat prevention temperature calibration function	
The temperature specified for the overheat prevention device is automatically recalibrated	—
when temperature reading is corrected with Calibration offset.	
Keypad lock (Lock)	
This function locks all the keys that may change setting values.	P.24
This setting can be made from Submenu.	
Auto-resume mode select (Pon)	
This is to select whether unit remain standby or resume operation at the time of recovery	
from power failure.	P.25
failure occurred	
This setting can be made from Submenu.	
Independent overheat prevention device	
The BOA201 type has a built in independent overheating prevention device that is fixedly	D 22
set at 230 ° C and the BOA311 type at 300 ° C. It will be activated if the above automatic	Γ.ΖΖ
overheating prevention device and overheating prevention device do not work.	

Mode & Function Flow



The following chart illustrates operation flow of Constant temperature operation and Submenu.

STOP

Program Operation Starts

PRE-OPERATIVE PREPARATIONS

operation precautions

Exercise caution in regard to the following.

- ① Connect unit to a power distribution board having sufficient capacity.
- 2 Never move unit while in operation.
- ③ Take sufficient measures against burns, such as using thick leather gloves.
- ④ During and after use, the chamber interior and the device are hot. Do not touch it with bare hands. In particular, the edge of the bath is hot, so do not touch it.
- 5 Do not operate the drain valve until the oil temperature drops below 45 °C.
- 6 Do not leave unit unattended during operation.
- The medium that can be used with this product is water (ion-exchanged water / distilled water) when used as a water bath, and silicone oil when used as an oil bath. Never use any liquid other than water or silicone oil.
- 8 Please refrain from using the water bath and oil bath together as it may cause an unexpected accident and is dangerous.
- (9) Do not place or operate unit outdoors.

About the medium liquid to be used.

When used as an aquarium

This product can be used as an aquarium from room temperature to around 95 °C. When using it as a water bath, it is recommended to use ion-exchanged water or distilled water to prevent the can stones from adhering to the heater and the bath. However, the temperature setting at the time of shipment is optimally set for the oil bath, and when water is used, the temperature control accuracy and temperature distribution accuracy will deteriorate.

When silicone oil is used as an oil bath

Use heat-resistant dimethyl silicon oil for open system heat transfer only, and Kinematic viscosity of 100mm2/s (cSt) or less.

Recommended silicon oil:

Temperature for use Below 200 °C Toshiba Silicone Co.,Ltd. TSF458-50 Temperature for use 200 °C ~ 270 °C. Toshiba Silicone Co. Ltd. TSF458-100

	Temperature for use 200 °C \sim 270 °C Toshiba Silicone Co.,Ltd. TSF458-10		
	Manufacturer	Toshiba Silicone	Toshiba Silicone
	Recommended temperature	200 °C or less	200 °C~270 °C
ha	Product name	TSF458-50	TSF458-100
rac	Unit Overview	Light yellow	Light yellow
te		transparent	transparent
risti	Relative density (25 °C)	0.961	0.963
CS	Viscosity (25 °C) mm2 / s (cSt)	50	100
ofs	Volatile content (150 °C, 24h)%	0.3	0.3
silic	Viscosity temperature coefficient	0.59	0.59
one	Flash point (°C)	325	342
0	Pour point (°C)	-50 °C or less	-50 °C or less
	Viscosity increase rate (300 °C, 168h)%	40	35
The deterioration rate (viscosity change) of silicone oil varies depending on the			

The deterioration rate (viscosity change) of silicone oil varies depending on the temperature used.

Especially in the case of TSF485-100 used at a temperature exceeding 200 °C, as a guide, almost no change in viscosity is seen at 200 °C, but it is about 1000 hours at 250 °C and 100 hours at 270 °C.

For details, please contact the silicone oil manufacturer at the time of purchase.

PRE-OPERATIVE PREPARATIONS



4. Preparation for operation

Overheat Prevention Device Setup

Setting range/function

The overheat prevention device temperature setting range is from 0 °C to 20 °C (BOA201 : 220 °C, BOA311 : 290 °C)beyond the maximum temperature setting of this unit.

When chamber temperature exceeds objective temperature setting and reaches that of the overheat prevention device, the heater circuit is shut off and error code "Er19" is shown flashing in the control panel display, accompanied by a sounding alarm.

Once activated, "Er19" continues to be displayed until ELB is turned off, then back on.

Setting temperature for overheat prevention



HEATER ALARM

CAUTION

1. Turn ON (|) ELB

Initial values will be shown for about five seconds after power-on, then displays will switch to the initial settings screen, showing current chamber temperature (top), operation mode character (center) and overheat prevention setting (bottom).

2. Set temperature for overheat prevention

- Press the SUB MENU key for about two seconds. Character in top display will flash.
- ② Press the ▼▲ keys several times until □ → H shows in top display.
- ③ Press the confirm key for about 2 seconds to display the current temperature indicator.

Note: To prevent false errors, set the value 10 °C or more above the main temperature setting.

- (4) Set the temperature using the \blacksquare keys.
- 5 Press the ENTER key or the FIXED TEMP. key to finalize the setting.
- * Setting change can also be made during operation.
- ① Overheat prevention device is designed to protect unit against overheating, to prevent damage to human body, not to protect test samples against damage caused by overheating, nor to protect against injury or death resulting from negligence from processing explosives, inflammables or other hazardous substances in this unit.
- ② Operation may be terminated by overheat prevention device activation, when overheat prevention device temperature setting and unit target temperature are less than 10 °C apart. The default settings are BOA201: 210 °C and BOA311: 280 °C.

Fixed Temperature Operation

Run a Fixed temperature operation





HEATER Տս r ALARM SET TEN FIXED TEMP





1. Turn ON (|) power (ELB)

Initial values will be shown for about five seconds after poweron, then displays will switch to the initial settings screen, showing current chamber temperature (top), operation mode character (center) and overheat prevention setting (bottom). Top: Shows current temperature in the chamber and other setting information. Center: Shows temperature setting and other setting information. Bottom: Displays the temperature setting of overheat prevention device.

For more on mode and setting characters, see "Display Characters" (P.11).

- 2. Set the temperature
- Press the FIXED TEMP. key 1

F, II, signifying Fixed temperature operation, will show in center display.

5. signifying temperature setting, will show in top display. Current temperature will flash in center display. FIXED TEMP lamp also flashes.

- Set the temperature using the \checkmark keys. 2
- 3 Press the ENTER key to finalize the setting.

3. Start operation

(4) Press the RUN/STOP key for about one second. The operation has started, and it is installed in the fixed value operation lamp and the main body control unit.



The operation indicator lamp turns on when you press the RUN/STOP key on the controller and starts operation, and turns off when you stop operation.

Fixed Temperature Operation



4. Stop operation

(5) Press the <u>RUN/STOP</u> key for about one second. Operation will stop (terminate) and the FIXED TEMP lamp and the operation indicator lamp installed in the main unit control unit will go out. Control panel reverts to initial settings screen.

• Setting value loop function

When setting temperature by the \bigtriangledown or \blacktriangle key, the setting value cycles in the setting range; when it reaches the maximum settable value, it returns to minimum and goes up again.

·Editing and confirming settings

Changing Temperature during operation is possible by pressing the FIXED TEMP key. Use the

▼▲ keysto change the setting values. Press the ENTER key when changes have been entered.

OPERATION PROCEDU

Independent overheat prevention device function

This product has a built-in hydraulic overheating prevention device that is independent of the controller. The operating temperature is about 230 °C (fixed) for BOA201 and about 300 °C (fixed) for BOA311. Even if the temperature inside the bath rises due to a controller malfunction, it will automatically reach about 230 °C or 300 °C. Turn off the breaker (o) to cut off the power supply to the main unit.

After the temperature inside the bath returns to below the operating temperature (230 °C or 300 °C), turn on the breaker (|) to restore the power.

This product has a triple overheating prevention function due to the automatic overheating prevention function, overheating prevention function and the above independent overheating prevention device.



If the independent overheating protector is activated, the circuit may be defective. Immediately disconnect the power cord and make a service call to your local dealer, our sales office, or the customer service center.

Emergency stop switch function

This product is equipped as standard with an emergency stop switch in case of a fire. When the emergency stop button is pressed, the breaker is automatically turns off (o) and the power to the main unit is cut off.

During normal operation, do not use the emergency stop switch to stop the operation.



In an emergency, press the emergency stop press strongly. To release it, turn the emergency stop switch to the right and turn on ()) the breaker.

Other Functions: Calibration Offset

Use the calibration offset function

The calibration offset function is a function that corrects the measured temperature of the controller.

Offset function can correct to either the positive or negative side of the entire unit temperature range. Offset function can be set or cancelled with the SUBMENU key.

Default setting is "0.0 °C", and setting range is "-15.0 to +15.0 °C"



- Run unit in Fixed temperature operation. When temperature stabilizes, gauge chamber temperature with a thermograph.
- Check the differences between display temperature and bath temperature.
 - ① Press the SUB MENU key for about two seconds.
 - ② Select ⊆ RL, signifying calibration offset, using the ▲▼ keys.
 - ③ Press the ENTER key.
 - ④ Enter a value that brings temperature display (top display) and chamber temperature into agreement, using the ▲▼ keys.
 - (5) Press the ENTER key or the FIXED TEMP. key to finalize the setting.

Setting change can also be made during operation.

Calibration offset can be set either the positive or negative side of 0. Setting calibration offset to the negative side of 0 increases actual temperature by the negative value entered (i.e. entering a value of -3 increases actual temperature by 3°C).

Setting calibration offset to the positive side of 0 decreases actual temperature by positive value entered (i.e entering +3 decreases actual temperature by 3°C

- Entering excessive compensation values may cause a precariously large discrepancy between actual temperature and temperature reading.
- In addition to the calibration offset function, this unit has a twopoint offset function built in, which has some compensating effects in low and high temperature zones. These offsets have already been entered at the factory.
- Contact original dealer of purchase when it becomes necessary to validate temperature controller.





Other Functions: Keypad Lock

·Using keypad lock

This function locks all the keys that may change setting values. With the keypad lock function ON, all keys become unresponsive except the RUN/STOP and SUBMENU keys. (will show in top display)



Default setting is "oFF".

- ① Press the SUB MENU key for about two seconds.
- (2) Select Loch, signifying Keypad lock function, using the \blacktriangle .
- ③ Press the ENTER key.
- ④ Center display will read "oFF" or "on". Use the ▼▲ keys to change the setting.
- ⑤ Press the ENTER key or the FIXED TEMP. key to finalize the setting.
- * Setting change can also be made during operation.



Other Functions: Auto-resume Function

 Auto-resume mode select Unit may restart operation or may be switched into standby state after power failure, by selecting "on" or "oFF" of this mode. With this setting "on" unit automatically resume operation, and remain standby when set to "oFF". Default setting is "oFF".

- ① Press the SUB MENU key for about two seconds.
- ② Select Pon, signifying Auto-resume function, using the ▲▼ keys.
- HEATER

2 sec

- ③ Press the ENTER key.
- ④ Center display will read "oFF" or "on". Use the ▼▲ keys to change the setting.
- (5) Press the ENTER key or the FIXED TEMP. key to finalize the setting.
- * Settings cannot be changed during operation.



* If "on" is set and the breaker is turned on (|) after the emergency stop switch is turned on during the fixed operation or after the independent overheating prevention device is activated, the fixed value operation is restored. Set "on" appropriately.

Various output terminal functions

·Before use



Operate this unit according to the procedure described in this Instruction manual. Failure to follow the operation procedure described herein may result in a problem. The guarantee will not apply if you operate the unit in a wrong manner.

Ω	1. Turn OFF (\bigcirc) ELB before connecting the cables.
U	2. For external alarm output, ensure that the input current is no greater than contact capacity shown in the specification table.
	3. Connect a recorder or another appliance of 600Ω or less in input impedance to the temperature output terminal.
	4. Securely fasten all connections with the screws attached to the terminal block.
	5. For the external alarm output, the non-voltage a contact from the terminal block becomes "ON = closed" when an error (Er ** display) occurs.
	6. Use a shielded wire for the cable to be connected to prevent noise.

Connection instructions

Remove the two screws that secure the sheet metal cover in the figure below, and remove the clear cover that comes with the terminal block.

Connect the external communication terminals to RS-485 A and B of the terminal block, the temperature output terminals to ANALOG + and-, and the external alarm output to ALARM COM and NO (M4 screw), respectively.



Various output terminal functions

Specifications

External alarm output terminal (ALARM)	 While some error occurs and the error code is displayed (Er ** is displayed), the non-voltage a contact is output as "ON = closed". Even if you mute the alarm buzzer on the main unit, the external alarm output continues as long as the error code is displayed. See "Reading Error Codes" (P.67) for details on errors. Contact configuration : No voltage a contact (relay contact) Contact capacity: AC250V 3A (resistive load), DC30V 3A (resistive load) Ensure that the input current is no greater than contact capacity shown above. Connection: M screw terminal block
External communications terminal (RS-485)	 Connection: M4 screw terminal block Connection: M4 screw terminal block * Refer to P.29 "Overview of external communication terminals" and subsequent pages for an overview of specifications.
Temperature output terminal (ANALOG)	 Outputs the current or voltage corresponding to the measured temperature. Temperature output range: 0 to 200 ° C (BOA201), 0 to 270 ° C (BOA311) * The above is the temperature output range at the time of initial setting, and the range can be changed. Output current: 4-20mA, output voltage: 1-5V * Current or voltage output can be selected with the changeover switch. Output accuracy: ±2 °C Connection: M4 screw terminal block

Temperature output terminal Temperature vs. Output Current conversion table

BOA201 Temperature (°C)	BOA311 Temperature (°C)	Output Current (mA) Changeover switch 4-20mA side	Output voltage (V) Changeover switch 1-5V side
0	0	4.0	1.0
50	67.5	8.0	2.0
100	135	12.0	3.0
150	202.5	16.0	4.0
200	270	20.0	5.0

* The temperature in the table is the output range at the time of initial setting and can be changed. See next page for how to change.

Temperature Output TerminalOutput current value and voltage value calculation formula

Output current mA = ((20mA-4mA) x current measured temperature) / (Temperature output range upper limit-Temperature output range lower limit) + 4mA

Output voltage V = $((5V-1V) \times current measured temperature) / (Temperature output range upper limit-Temperature output range lower limit) + 1V$



How to set the temperature output terminal output range

How to set the temperature output range

The temperature output terminal can set the temperature output range arbitrarily between -100.0 and 300.0 °C.

The default settings are BOA 201: 0 to 200 $^\circ\text{C}$ and BOA 311: 0 to 270 $^\circ\text{C}.$



2 sec





- ① Press the SUB MENU key for about two seconds. Character in top display will flash.
- ② Press the **V** keys to select the character tr that represents the temperature output scaling setting.
- ③ Press the ENTER key.
- ④ Top display will show , indicating that the lower limit of t emperature output range can be set. Current setting will flash in center display.

Use the \checkmark keys to set the desired lower limit of the temperature output range.

* Press the fixed temperature key during display to confirm the set value and return to the initial screen.

- 5 Press the ENTER key.
- (6) Top display will show , indicating that the upper limit of temperature output range can be set. Current setting will flash in center display.

Use the \checkmark keys to set the desired upper limit of the temperature output range.

* Press the fixed temperature key during display to confirm the set value and return to the display.

- O Press the confirm key to return to the initial screen.
- * Settings cannot be changed during operation. , indicating that the setting cannot be changed, will show in STEP (4) and (6).
- * Both trL and trH can be set to any value in the setting range: 100.0 to 300.0 $^{\circ}$ C.
- * If both trL and trH are set to the same setting such as 0.0 $^{\circ}$ C, the output will be fixed at 4mA.

Also, for example, if trL: 0.0 $^{\circ}$ C and trH: -0.1 $^{\circ}$ C are set, the output of about 1mA will continue.

To release it, set trH to 0.0 $^\circ$ C or higher, and then turn the breaker OFF (\circ) / ON (|).

Depending on the setting, the output may be 1mA as described above, so pay close attention to the setting value.

Overview of external communication terminals

Introduction

RS-485 allows to set or monitor data of the controller of this unit by building a program on host computer.

|--|

Item	Communication settings	
Communication interface standard	EIA standard, based on RS-485	
Synchronous method	asynchronous communication method	
Communication method	Two-wire half-duplex	
Transmission code	ASCII	
Communication rate	2400/4800/9600/19200/38400bps	
Communication range	Up to 500 m (results may vary depending on the environment)	
Network	Multi-drop method (max 31 hosts to each node)	
Stop bit length	1/2bits	
Data length	7/8bits	
Parity bit	None/Odd/Even	
Error detection	Toho : BCC Modbus-RTU : CRC-16 Modbus- ASCII : LRC	
Response delay time	0 to 250 msec	

Note: is default setting.

Connection

∎ PC

·A USB interface is used

- USB-RS485 converter unit
 - For the converter, System Sacom's USB-485 is applicable.
 - Optional accessory "External communications adapter (RS485-USB) OA017" permits the following connections.
 - (PC not included)

 $Sample \ program \rightarrow \underline{http://www.yamato-net.co.jp/support/program/index.htm}$



USB-RS485 converter unit: System Sacom USB-485I RJ45-T4P

Communication cable: UL2464TASB 2-lead AWG20 cable 3 m, with Y terminal on main unit side. USB cable: 1.8 m, included with USB-485I

* It may be effective to use a commercial braided shield USB cable for noise resistance.

Communication settings

	ltem	Communication settings	Default values
1	Communication protocol	Toho (0)/Modbus-RTU (1)/ Modbus-ASCII (2)	Toho (0)
2	BCC check	Enable (b)/Disable (n)	Enable (b)
3	Data length	7/8 bits	8 bits
4	Parity bit	None (n)/odd (o)/even (E)	None (n)
5	Stop bit length	1/2 bits	2 bits
6	Communication rate	2400 (24)/4800 (48)/ 9600 (96)/19200 (192)/ 38400 (384) bps	4800 (48) bps
7	Auxiliary address	1-99 units (1:31 stations at maximum)	1
8	Response delay time	0-250 msec	0 msec
9	Communication mode	Read only (ro)/ Read/Write (rW)	Read/Write (rW)

Setting items and parameters for this controller is defined in the table below.

* For how to change the communication settings on the product side, refer to "Communication parameter setting method" below.

Remote communication parameter setting (option)



Remote communication parameter setting (option)



HEATER
 ALARM
 SET
 FIXED TEMP.
 OVER TEMP.



HEATER ALARM FIXED TEMP. FIXED TEMP. OVER TEMP. O

(10)

SUB MENU

(6) The character bcc indicating the BCC check setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display.

Use the **▼▲** keys to set the desired settings. "N": None / "b": Yes

- ⑦ Press the ENTER key.
- * Press the fixed temperature key during display to confirm the set value and return to the display.
- ⑧ The character dAt indicating the date length setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display.

Use the **▼▲** keys to set the desired settings. "7": 7 bits /: "8" 8 bits

- 9 Press the \fbox{ENTER} key.
- * Press the fixed temperature key during display to confirm the set value and return to the display.
- The character PAL indicating the parity setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display. Use the ▼▲ keys to set the desired settings. None (n)/odd (o)/even (E)

1 Press the ENTER key.

* Press the fixed temperature key during display to confirm the set value and return to the display.



The character SPb indicating the stop bit setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display. Use the V A keys to set the desired settings.
 "1": 1 bit / "2": 2 bits

1 Press the ENTER key.

* Press the fixed temperature key during display to confirm the set value and return to the display.
Remote communication parameter setting (option)











- The character bPS indicating the communication rate setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display.
 - Use the \checkmark keys to set the desired settings.
 - [24]: 2400bps/ [48]: 4800bps/ [96]: 9600bps/ [192]: 19200bps/ [384]: 38400bps
- 15 Press the ENTER key.
- * Press the fixed temperature key during display to confirm the set value and return to the display.
- (f) The character Adr indicating the avxiliary address setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display.

Use the \checkmark keys to set the desired settings.

Setting range: 1 to 99 (stations), but up to 1 to 31 stations

- 1 Press the \fbox{ENTER} key.
- * Press the fixed temperature key during display to confirm the set value and return to the display.
- (18) The character AWt indicating the response delay time setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display.

Use the **▼**▲ keys to set the desired settings. Setting range: 0 to 250 msec

- (19) Press the ENTER key.
- * Press the fixed temperature key during display to confirm the set value and return to the display.
- If the character Mod indicating the mode setting is displayed on the measurement temperature display, and the current setting is displayed blinking on the set temperature display. Use the ▼▲ keys to set the desired settings.
 "Ro": read-only / "rW": read / write
- 1) Press the confirm key to return to the initial screen.
- * Press the fixed temperature key during display to confirm the set value and return to the display.

Communication procedure

This unit returns a "reply message" to a "request message" from the host computer but does not start transmission.

• This unit does not start communication (no reply) for about five seconds after the power is turned on. Set a delay until communication begins after the power is turned on.



Communication message type

The types of communication messages can be broadly divided as follows.



34

Configuration of Toho protocol request message (sending from host compute r to this product)

■ For the codes from ① to ⑦, refer to P.37 "Explanation of Toho Protocol Codes".

■ Refer to P.40 "Toho Protocol Read Communication Example" and P.41 "Toho Protocol Write Communication Example" for specific request message examples.

Structure of read request message



Structure of write request message



- 2 Avxiliary address
- ③ Request
- (4) Indentifier
- (5) Numeric data
- 6 End code
- ⑦ BCC code

Configuration of Toho protocol response message (sending from this produc t to host computer)

■ For the codes from ① to ⑩, refer to next page "Explanation of Toho Protocol Codes".

■ Refer to P.40 "Toho Protocol Read Communication Example" and P.41 "Toho Protocol Write Communication Example" for specific request message examples.

Response message to read request message



Response message to read request message



Response message when there is an error



- ① Start code
- 2 Avxiliary address
- ③ Request
- ④ Indentifier
- (5) Numeric data
- ⑥ End code
- ⑦ BCC code
- 8 Positive code
- 9 Negative code
- 1 Errer code

Code description for the Toho protocol

- The following codes ① STX address to ⑪ error type are represented by ASCII codes.
- For ASCII codes, p.59 "List of ASCII Codes."

■ Refer to P.40 "Toho Protocol Read Communication Example" and P.41 "Toho Protocol Write Communication Example" for conversion to ASCII code.

1) STX

This code is required for the receiving side to detect the beginning of the message. Add it to the beginning of the character string to be sent.

② スレーブアドレス

This is the avxiliary address of the unit with which the host computer communicates. The avxiliary address within a reply message from the unit indicates the unit that has transmitted the message.

- ③ Request details
 - Enter the symbol "R" or "W."
 - R: To read data from the unit
 - W: When writing data to this product
- ④ Identifier

This is the classification symbol (identifier) of the data to be read or written and represented by a three-digit alphanumeric ASCII code. Refer to the various commands on P. ~.

5 Numerical data

This is the data to be read or written and always represented by five digits, irrespective of the type.

Negative data: The symbol "-" symbol to the 5th digit. Position of decimal point: Five-digit data does not include any decimal point.

Example) The meaning of the five-digit numeric data 00123 is shown in the table below.

example	Meaning of numbers
Set temperature SV1 (with decimal point)	12.3°C

Example2) The meaning of the five-digit numeric data -0004 is shown in the table below.

example	Meaning of numbers
Measurement temperature PV1 (with decimal point)	-0.4°C

6 ETX

This code is required for the receiving side to detect the end of the message. Add it to the final of the character string to be sent. (If there is BCC, before BCC)

Code description for the Toho protocol

⑦ BCC

This is the check code for error detection and takes the exclusive OR (EX-OR) of all characters from STX to ETX.

When "Disabled" is selected for BBC check among the communication settings for the unit, this code (BCC) will not be included in the reply message.

8 ACK

Positive code. This is an included and returned in the "reply message" from the unit when no error is found in the received message.

9 NAK

Negative code. This is an included and returned in the "reply message" from the unit when error is found in the received message.

1 Error number

If there is an error in the "request message" received by this product, the error number (number in the table below) is included after "@NAK" in the "response message".

When there is a compound error, the error number with the higher number is included.

Error	Details of the error in the "request message" received by this product
number	
1	Numerical data was out of the "setting range individually specified by the
	setting item"
2	Change of requested item is prohibited or there is no item to read
	ASCII code other than numerical data was specified in the place of numerical
3	data
	An ASCII code other than a number or "-" was specified at the sign position.
4	Format error
5	BCC error
6	Overrun error
7	Framing error
8	Parity error

Precautions for Toho protocol communication

(1) Transmission / reception timing

When using communication, set a sufficient response delay time to ensure that the host computer switches from transmission to reception. Refer to the figure on page 33 "Communication procedure".

(2) Request interval

When sending a "request message" continuously from a host computer, wait at least 2 msec after receiving the "response message" from this product before sending.

(3) Response conditions

This product will not reply to the "response message" unless STX and ETX (BCC) are included in the "request message".

Therefore, even if there is an error in the "request message", the "response message" (error reply) containing NAK and error number will not be returned unless the above conditions are met.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again. When this product receives STX, all the codes received before that will be cleared.

(4) Error specifying avxiliary address

This product does not respond to any "request message" that specifies a avxiliary address other than the one set for itself. Therefore, if there is an error in the avxiliary address part in the "request message", the "response message" will not be returned.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again. When this product receives STX, all the codes received before that will be cleared.

(5) Operation when the power is turned on

This unit does not start communication (no reply) for about five seconds after the power is turned on.

Set a delay until communication begins after the power is turned on.

(6) Decimal point of temperature data

This product does not add a decimal point or data suggesting a decimal point to the temperature data.

Please convert the data on the computer side.

Toho protocol read communication example

Request message: Requests "measurement temperature read" to the product set to the avxiliary address "01".

Response message: Return the measured temperature data "12.3 °C (00123)".

Read request message (sent from host computer)



Response message (response from this product)



code	Symbol / data	ASCII code
① Start code	STX	02h
② Avxiliary address	01	30h 31h
③ Request contents (reading)	R	52h
(4) Identifier	PV1	50h 56h 31h
5 Numerical data	00123	30h 30h 31h 32h 33h
6 End code	ETX	03h
⑦ BCC data Request		65h
Response		01h
8 Positive code	ACK	06h

Toho protocol write communication example

Request message: Requests "write to set temperature 13.5 °C (00135)" for this product set to avxiliary address "01".

Reply message from the unit to this request message: Information that the request message has been received is returned.

Confirm that the data has been properly written by reading it separately.

Write request message (sent from host computer)



Response message (response from this product)



code	Symbol / data	ASCII code
① Start code	STX	02h
② Avxiliary address	01	30h 31h
③ Request contents (writing)	W	57h
④ Identifier	SV1	53h 56h 31h
5 Numerical data	00135	30h 30h 31h 33h 35h
6 End code	ETX	03h
⑦ BCC data Request		54h
Response		06h
8 Positive code	ACK	06h

Modbus-RTU request message configuration (sending from host computer to this product)

■ For the codes from a) to g), refer to P.44 "Explanation of Modbus-RTU Code".

Structure of read request message

	roud roquoot mooodyo			
			(exampl	e)
a)	Avxiliary address		01h	
b)	Function code		03h	
		Тор	10h	
c)	Register address	Lower level	00h	Register address
		Тор	00h	
d)	Number of registers	Lower level	02h	Two are fixed
e)	CRC-16	Lower level	C0h	
		Тор	CBh	

Structure of write request message

	1 5		(example	e)
a)	Avxiliary address		01h	
b)	Function code		10h	
		Тор	10h	
c)	Register address	Lower level	00h	Register address
		Тор	00h	
d)	Number of registers	Lower level	02h	Two are fixed
f)	Number of bytes		04h	Number of registers x 2
	Data to the first register	Тор	00h	3
a)	(Lower word)	Lower level	00h	The data structure is 1234 h.
y)	Data to the first register	Тор	00h	① (① represents 1 byte)
	(Upper word)	Lower level	00h	2
e)	CRC-16	Lower level	3Eh	
		Тор	6Fh	J

Modbus-RTU response message configuration (sending from this product to host computer)

■ For the codes from a) to h), refer to next page "Explanation of Modbus-RTU Code".

Response message to read request message

196	message to read request n	lessaye		
		-	(examp	le)
a)	Avxiliary address		01h	
b)	Function code		03h	
f)	Number of bytes		04h	Number of registers x 2
	Data to the first register	Тор	00h	3
a)	(Lower word)	Lower level	64h	(4) The data structure is (1234) h.
g)	Data to the first register	Тор	00h	① (① represents 1 byte)
	(Upper word)	Lower level	00h	2
e)	CRC-16	Lower level	BBh	
		Top	ECh	

Response message to read request message

			(exampl	e)
a)	Avxiliary address		01h	
b)	Function code		10h	
-		Тор	10h	
c)	Register address	Lower level	00h	First register address
		Тор	00h	
d)	Number of registers	Lower level	02h	Two are fixed
e)	CRC-16	Lower level	45h	
		Тор	08h	

Response message when there is an error

			(example	э)
a)	Avxiliary address		01h	
b)	Function code		83h	•
h)	Error Codes		02h	8
	050.40	Lower	C0h	
e)	CRC-16	level		
		lop	F1h	

 \leftarrow In case of error, the value of function + 80 h of the request message is entered.

Modbus-RTU code description

The following a) avxiliary address to h) error code are expressed in 8-bit binary.

a) Avxiliary address

This is the avxiliary address of the other party (this product) with which the high level computer communicates.

The avxiliary address in the response message from this product indicates the source of the response message.

b) Function code

Please enter the code for 03h or 10h.

03h: When reading data from this product / 10h: When writing data to this product

c) Register address

Specify the position of the data to be read or written in 2 bytes.

For the address of each command, refer to the various commands on page P. $50 \sim 58$ The data is stored in the holding register.

d) Number of registers

Specifies the number of registers to write. Since the number of registers of this product is fixed at 2, specify 0002h.

e) CRC-16

This is an error check code for detecting an error in a message. Send CRC-16 (Cyclic Redundancy Code).

The CRC-16 generation polynomial used in this product is $X^{16} + X^{15} + X^2 + 1$. If you want to add it to the end of the message as an error code, add it in the order of the lower byte and the upper byte of CRC.

f) Number of bytes

Specify the number of registers to read and write x 2. Since the number of registers of this product is fixed at 2, 04h is specified here.

g) Data

Specifies the data to write to the register. The data is fixed at 4 bytes.

If the data has a decimal point, write the data without the decimal point.

Also, when reading data, determine the presence or absence of a decimal point on the computer side.

The data in parentheses is the value when actually used for the transmitted message. For details, refer to P.48 "Modbus-RTU Request Message Configuration (Sending from the high level computer to this product)".

For numerical data with a decimal	point
Communication content	HEX data
Measurement temperature = 10.5	00000069h (00690000)
Measurement temperature = -10.5	FFFFF97h (FF97FFFF)

. . . 1ith . .

h) Error code

If there is an error in the message from the high level computer, "Response message" from this product.

When there is a compound error, the error number with the higher number is included. The details and classification of the errors are as shown in the table below.

Error number	Details of the error in the "request message" received by this product
01	Irregular/incorrect function code received
02	Received an address other than the specified address
03	Numerical data was out of the "setting range individually specified by the setting item"

Modbus-RTU Code Communication Precautions

(1) Transmission timing

When using communication, set a sufficient response delay time to ensure that the host computer switches from transmission to reception.

Refer to the figure on page 33 "Communication procedure".

(2) Request interval

When sending a "request message" continuously from a high level computer, wait at least 2 msec after receiving the "response message" from this product before sending.

(3) Response conditions

If the time interval between the data that make up the "request message" is 3.5 characters or more, this product cannot be recognized as one "request message" and will not return the "response message".

Therefore, even if there is an error in the "request message", the "response message" (error reply) containing error code will not be returned unless the above conditions are met.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again.

When this product opens a time interval of 3.5 characters or more, all codes received before that will be cleared.

(4) Error specifying avxiliary address

This product does not respond to any "request message" that specifies a avxiliary address other than the one set for itself.

Therefore, if there is an error in the avxiliary address part in the "request message", the "response message" will not be returned.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again.

- (5) Number of digits of data and position of decimal point See P.51 "Modbus-RTU Code Description g) Data".
- (6) Operation when the power is turned on

This unit does not start communication (no reply) for about five seconds after the power is turned on.

Set a delay until communication begins after the power is turned on.

(7) Decimal point of temperature data

This product does not add a decimal point or data suggesting a decimal point to the temperature data.

Please convert the data on the computer side.

Modbus-RTU read communication example

Request message: Requests "measurement temperature read" to the product set to the avxiliary address "01".

Response message: Return the measured temperature data "10.0 ° C".

Read request message (sent from host computer)



Response message (response from this product)

01	03	04	00	64	00	00	BB	EC
1	2	5		— (6) —		_ (D -

code	Symbol / data	ASCII code
 Avxiliary address 	01 (0x01)	01h
2 Function code	03 (0x03)	03h
③ Register address	0x0100	01h 00h
④ Number of registers	2 fixed (0002)	00h 02h
⑤ Number of bytes	4 fixed (04)	04h
6 Numerical data	100 (00000064h)	00h 00h 00h 64h
⑦ CRC-16 Request		F7h C5h
Response		ECh BBh

Modbus-RTU write communication example

Request message: Requests "write to set temperature 15.0 ° C" for this product set to avxiliary address "01".

Reply message from the unit to this request message: Information that the request message has been received is returned.

Confirm that the data has been properly written by reading it separately.

Write request message (sent from host computer)



Response message (response from this product)



code	Symbol / data	ASCII code
1 Avxiliary address	01 (0x01)	01h
② Function code	10 (0x10)	10h
③ Register address	0x1002	10h 02h
④ Number of registers	2 fixed (0002)	00h 02h
⑤ Number of bytes	4 fixed (04)	04h
6 Numerical data	150 (00000096h)	00h 00h 00h 96h
⑦ CRC-16 Request		9Ah 5Fh
Response		C8h E4h

Modbus-ASCII request message configuration (sending from host computer t o this product)

■ For the codes from a) to i), refer to P.50 "Explanation of Modbus-ASCII Code".

Structure of read request message

a)	Start code		':' :	
b)	Avxiliary address		'0','1'	
c)	Function code		'0','3'	
-		Тор	'1','0'	
d)	Register address	Lower	יחי יחי	First register address
		level	0,0	
		Тор	'0','0'	
e)	Number of registers	Lower	10' 12'	Two are fixed
		level	0,2	
f)	LRC		'E','A'	
g)	End code		CR, LF]

Structure of write request message

a)	Start code		':'	
b)	Avxiliary address		'0','1'	
c)	Function code		'1','0'	
-		Тор	'1','0'	
d)	Register address	Lower level	'0','0'	First register address
		Тор	'0','0'	
e)	Number of registers	Lower level	'0','2'	Two are fixed
h)	Number of bytes		'0','4'	Register x 2
-	First register data	Тор	'0','0'	3
i)	(Lower word)	Lower level	'0','0'	(4) The data structure is (12)(3)(4)h.
1)	First register data	Тор	'0','0'	① (① represents 1 byte)
	(Upper word)	Lower level	'0','0'	2
f)	LRC		'D','9'	
g)	End code		CR, LF]

Modbus-ASCII request message configuration (sending from this product to host computer)

■ For the codes from a) to j), refer to next page "Explanation of Modbus-ASCII Code".

Response message to read request message

	V			
a)	Start code		:	
b)	Avxiliary address		'0','1'	
c)	Function code		'0','3'	
h)	Number of bytes		'0','4'	Re
i)	First register data	Тор	'0','0'	3
	(Lower word)	Lower level	'0','0'	4
i)	First register data	address ''' address '0','1' code '0','3' of bytes '0','3' f bytes '0','0' ter data Top bord) '0','0' ter data '0','0' Lower '0','0' level '0','0' ter data Top bord) '0','0' Lower '0','0' CR, LF 'F','8'	1	
1)	(Upper word)	Lower	'0','0'	2
f)	LRC	•	'F','8'	
g)	End code		CR, LF	

egister x 2

The data structure is 1234h.

(1) represents 1 byte)

Response message to read request message

a)	Start code			
b)	Avxiliary address		'0','1'	
c)	Function code	'1','0'		
-		Тор	'1','0'	
d)	Register address	Lower level	'0','0'	First regi
		Тор	'0','0'	
e)	Number of registers	Lower level	'0','2'	Two are
f)	LRC		'D','D'	
g)	End code		CR, LF	

ister address

fixed

Response message when there is an error

a)	Start code	
b)	Avxiliary address	'0','1'
c)	Function code	'8','3'
j)	Error Codes	'0','2'
f)	LRC	'7','A'
g)	End code	CR, LF

 \leftarrow In case of error, the value of function + 80h of the request message is entered.

Modbus-ASCII code description

The following a) start code to j) error code are expressed in ASCII code.

■ For ASCII codes, p.59 "List of ASCII Codes."

■ Refer to P.40 "Modbus-ASCII Read Communication Example" and P.41 "Modbus-ASCII Write Communication Example" for conversion to ASCII code.

a) Start code

This code is required for the receiving side to detect the beginning of the message. Add it to the beginning of the character string to be sent.

b) Avxiliary address

This is the avxiliary address of the other party (this product) with which the high level computer communicates.

The avxiliary address in the response message from this product indicates the source of the response message.

c) Function code

Please enter the code for 03h or 10h.

03h: When reading data from this product / 10h: When writing data to this product

d) Register address

Specify the position of the data to be read or written in 2 bytes. For the address of each command, refer to the various commands on page P. $50 \sim 58$

e) Number of registers

Specifies the number of registers to write. Since the number of registers of this product is fixed at 2, specify 0002h.

f) LRC

This is an error check code for detecting an error in a message. I will send you an LRC. The LRC used in this product is the data part excluding the start code and end code of the message. It is a two's complement of the answer, added without a carry. The parts represented by "1" and "B" in the data part are considered as "1Bh". If 12h is calculated as an error code, add "1" and "2" after the message.

g) End code

This code is required for the receiving side to detect the end of the message. Add CR (0Dh) and LF (0Ah) to the end of the character string to be sent.

h) Number of bytes

Specify the number of registers to read and write x 2. Since the number of registers of this product is fixed at 2, 04h is specified here.

Modbus-ASCII code description

g) Data

Specifies the data to write to the register. The data is fixed at 4 bytes.

If the data has a decimal point, write the data without the decimal point.

Also, when reading data, determine the presence or absence of a decimal point on the computer side.

The data in parentheses is the value when actually used for the transmitted message. For details, refer to P.48 "Modbus-ASCII Request Message Configuration (Sending from the high level computer to this product)".

■ For numerical data with a decimal point

Communication content	HEX data
Measurement temperature = 10.5	0000069h (00690000)
Measurement temperature = -10.5	FFFFF97h (FF97FFFF)

h) Error code

If there is an error in the message from the high level computer, "Response message" from this product.

When there is a compound error, the error number with the higher number is included.

Error number	Details of the error in the "request message" received by this product					
01	Irregular/incorrect function code received					
02	Received an address other than the specified address					
03	Numerical data was out of the "setting range individually specified by the setting item"					
04	Instrument failure (when equipment abnormality occurs)					

Modbus-ASCII communication notes

(1) Transmission timing

When using communication, set a sufficient response delay time to ensure that the host computer switches from transmission to reception. Refer to the figure on page 33 "Communication procedure".

(2) Request interval

When sending a "request message" continuously from a high level computer, wait at least 2 msec after receiving the "response message" from this product before sending.

(3) Response conditions

This product will not return the "response message" unless the start code and end code are included in the "request message".

Therefore, even if there is an error in the "request message", the "response message" (error reply) containing error code will not be returned unless the above conditions are met.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again.

When this product receives start code, all the codes received before that will be cleared.

(4) Error specifying avxiliary address

This product does not respond to any "request message" that specifies a avxiliary address other than the one set for itself.

Therefore, if there is an error in the avxiliary address part in the "request message", the "response message" will not be returned.

Therefore, if the host computer does not return the "response message" within an appropriate time after sending the "request message", send the required "request message" again.

When this product receives start code, all the codes received before that will be cleared.

- (5) Number of digits of data and position of decimal point See P.51 "Modbus-ASCII Code Description g) Data".
- (6) Operation when the power is turned on

This unit does not start communication (no reply) for about five seconds after the power is turned on.

Set a delay until communication begins after the power is turned on.

(7) Decimal point of temperature data

This product does not add a decimal point or data suggesting a decimal point to the temperature data.

Please convert the data on the computer side.

Modbus-ASCII read communication example

Request message: Requests "measurement temperature read" to the product set to the avxiliary address "01".

Response message: Return the measured temperature data "10.0 ° C".



Response message (response from this product)



code	Symbol / data	ASCII code
① Start code	:	3Ah
② Avxiliary address	01 (0x01)	30h 31h
③ Function code	03 (0x03)	30h 33h
④ Register address	0x0100	30h 31h 30h 30h
5 Number of registers	2 fixed (0002)	30h 30h 30h 32h
6 Number of bytes	4 fixed (04)	30h 34h
⑦ Numerical data	100 (00000064h)	30h 30h 30h 30h 30h 30h 36h 34h
8 LRC Request	F9	46h 39h
Response	94	39h 34h
9 Encode	CR, LF	0Dh 0Ah

Modbus-ASCII write communication example

Request message: Requests "write to set temperature 15.0 $^\circ$ C" for this product set to avxiliary address "01".

Reply message from the unit to this request message: Information that the request message has been received is returned.

Confirm that the data has been properly written by reading it separately.

Write request message (sent from host computer)



Response message (response from this product)

:	0	1	1	0	1	0	0	2	0	0	0	2	D	В	C R	L F
1		2)	(3)		_ (4) —	-		_ (5) —	-	(8	3)		9

code	Symbol / data	ASCII code
1 Start code	:	3Ah
2 Avxiliary address	01 (0x01)	30h 31h
③ Function code	10 (0x10)	31h 30h
④ Register address	0x1002	31h 30h 30h 32h
5 Number of registers	2 fixed (0002)	30h 30h 30h 32h
6 Number of bytes	4 fixed (04)	30h 34h
⑦ Numerical data	150 (00000096h)	30h 30h 30h 30h 30h 30h 39h 36h
8 LRC Request	41	34h 31h
Response	DB	44h 42h
9 Encode	CR, LF	0Dh 0Ah

Precautions for setting by communication

- The W command is disabled when some setting screen is displayed by operating the keys on the product.
- During communication, the communication lamp on the upper left of the set temperature indicator on the operation panel of the product blinks.

Refer to the figure below for the communication lamp.

Operation setting command

Panel item	Letters	Modbus Address	Command	Setting value
Fixed value operation start / stop	RUN	0x1502	R/W	00000: Stop 00001: Start ※
Remote operation mode	RMT	0x1506	R/W	00000: Stop 00001: Remote operation mode
Signifies temperature setting mode	SV1	0x1002	R/W	Lower limit of set temperature to upper limit of set temperature ※

※ The W command is a valid parameter during fixed-value operation.

About remote operation mode

- When "1" is written in the remote operation mode when the product is stopped, the communication lamp on the upper left of the set temperature indicator on the operation panel lights up, and the communication lamp blinks in synchronization with the communication. Refer to the figure below for the communication lamp.
- All key operations on the product are disabled during remote operation, and the remote character rEmt is always displayed on the set temperature display on the operation panel when operation is stopped, and any key operation is performed during fixed-value operation. Display rEmt. Refer to the figure below for the display of rEmt.
- To cancel the remote operation mode, write "0" or turn off (\circ) / ON (|) the breaker and restart.
- If the remote operation mode is not set, the parameters can be changed by both key operation and communication, and there is a risk of double changes. Therefore, it is recommended to switch to the remote operation mode when rewriting the parameters.



Submenu command

Panel item	Letters	Modbus Address	Command	Setting value
Signifies overheat prevention setting mode	_OH	0x2004	R/W	Overheating prevention set temperature range
Calibration Offset temperature setting	PVS	0x2722	R/W	Calibration offset set temperature range ※1
Set keypad lock	LOC	0x1500	R/W	00000: Set value lock OFF
Signifies auto- resume function setting	PON	0x2618	R/W	00000: Power outage compensation OFF 00001: Power outage compensation ON
Lower limit of t emperature output range	TRL	0x2804	R/W	-1000(-100.0 °C)~03000(300.0 °C)
Upper limit of temperature output range	TRH	0x2806	R/W	-1000(-100.0 °C)~03000(300.0 °C)

%1 The W command is a valid parameter during fixed-value operation.

%2 The identifier _ means a space (ASCII: 20h).

Refer to P.58 "Communication Parameter Command" for communication parameters.

Monitor command

Panel item	Letters	Modbus Address	Command	Setting value
Measurement	PV1	0x0100	R	(example)
temperature				Toho Modbus
monitor				01000 000003E8h 100.0 °C (with decimal
				temperature overscale
				LLLLL 8000000h Measurement
				scale
Output monitor 1	OM1	0x0204	R	00000
				 1st digit: Heater output 2nd digit: Do not use. 3rd digit: Main relay output 4th digit: Do not use. 5th digit: Overheating prevention device output (normally ON) * Output status 0: Output OFF / 1: Output ON Example) Overheating prevention device output ON, main relay output ON Toho: 10100 Modbus: 00002774h
Output monitor 2	OM2	0x0206	R	00000

Monitor command

Panel item	Letters	Modbus Address	Command	Setting value
Abnormal alarm	ER1	0x020A	R	00000 1st digit: Memory abnormality (Er15) 2nd digit: Sensor error (Er01) 3rd digit: Do not use. 4th digit: Heater disconnection (Er03) 5th digit: SSR short circuit (Er02) XAbnormal state 0: No abnormality / 1: Abnormal Example) Sensor abnormality, heater disconnection Toho: 01010 Modbus: 000003F2h
Abnormal alarm	ER2	0x020C	R	00000 2nd digit: Water level error (Er20) 2nd digit: Do not use. 3rd digit: Overheating preventer activated (Er19) 4th digit: Internal communication error (Er17) 5th digit: Do not use. *Abnormal state 0: No abnormality / 1: Abnormal
Abnormal alarm	ER3	0x020E	R	00000 I Ist digit: Main relay contact short circuit error (Er10) 2nd digit: Do not use. 3rd digit: Do not use. 4th digit: Do not use. 5th digit: Do not use. XAbnormal state 0: No abnormality / 1: Abnormal
Operation status	RNM	0x0216	R	00000 U I I I I I I I I I I I I I I I I I I

Communication parameter command

Panel item	Letters	Modbus Address	Command	Setting value
Protocol settings	PRT	0x2500	R/W	00000: Toho 00001: Modbus-RTU 00002: Modbus-ASCII
BCC check	BCC	0x2502	R / W	Toho N: NoneB: Yes Modbus 0x00: None 0x01: Yes
Data length	DAT	0x2504	R/W	Toho 7: 7 bits8: 8 bits ※ Modbus 0x07: 7 bits 0x08: 8 bits
Parity bit	PAL	0x2506	R/W	Toho None (n)/Odd (o)/Even (E) Modbus 0x00: None 0x01: Odd 0x02: Even
Stop bit	SPB	0x2508	R/W	Toho 1: 1 bits2: 2 bits Modbus 0x01: 1 bit 0x02: 2 bits
Communication rate	BPS	0x250A	R / W	Toho 「2400」: 2400bps / 「4800」: 4800bps ※ 「9600」: 9600bps ∕ 「19200」: 19200bps 「38400」: 34800bps Modbus 0x01 : 2400bps 0x02 : 4800bps 0x03 : 9600bps 0x04 : 19200bps 0x05 : 38400bps
Avxiliary address	ADR	0x250C	R/W	Toho : 1~99 Modbus : 0x01~0x63
Response delay time	AWT	0x250E	R/W	0-250 msec
Communication mode switching	MOD	0x2510	R/W	Toho RO: Lead onlyRW: Lead light ※ Modbus 0x00: Lead only 0x01: Lead light

Setting value _ means a space (ASCII: 20h).

About external communication

ļ

When using external remote communication option on any unit, access by anything other than the above-mentioned reference addresses, may cause equipment malfunction. Do not attempt to use any reference address, code or utility other than those given above or as recommended by Yamato Scientific Co., Ltd.

ASCII code table

	00h	10h	20h	30h	40h	50h	60h	70h
00h	NUL	DEL	Space	0	@	Р	`	р
01h	SOH	DC1	!	1	Α	Q	а	q
02h	STX	DC2	"	2	В	R	b	r
03h	ETX	DC3	#	3	С	S	С	s
04h	EOT	DC4	\$	4	D	т	d	t
05h	ENQ	NAK	%	5	Е	U	е	u
06h	ACK	SYM	&	6	F	v	f	v
07h	BEL	ETB	•	7	G	W	g	w
08h	BS	CAN	(8	н	Х	h	x
09h	ΗТ	EM)	9	I	Y	i	У
0Ah	LF	SUB	*	••	J	Z	j	z
0Bh	VT	ESC	+	;	к	[k	{
0Ch	FF	FS	,	<	L	¥	Ι	Ι
0Dh	CR	GS	-	=	м]	m	}
0Eh	SO	RS		>	N	^	n	~
0Fh	SI	US	1	?	0	_	ο	DEL

*How to read ASCII code table

(ASCII code) = (TOP) + (LOWER) Example 1) In the case of "5": (35h) = (30h) + (05h)Example 2) In the case of "A": (41h) = (40h) + (01h)

Multi-drop connection example

This is an example of the multi-drop wiring method using the optional "external communication adapter (RS485-USB conversion) OA017".



USB-RS485 converter unit: System Sacom USB-485I RJ45-T4P

USB cable: 1.8 m, included with USB-485I

Communication cable 1: UL2464TASB 2-lead AWG20 cable 3 m, with Y terminal on main unit side. Communication cable 2: Custom-made items.

Terminating resistor: Custom-made item. If you prepare a terminating resistor yourself, connect a fixed resistor of 100 Ω and 1/4 W or over to the last cable appliance terminal block.

6. HANDLING PRECAUTIONS

Warnings and Cautions

NEVER process explosive or flammable substances

Never attempt to process explosives, flammables or any items which contain explosives or flammables. Fire or explosion may result. See " LIST OF HAZARDOUS SUBSTANCES" (P.72)

DO NOT insert foreign objects into unit openings.

In the event that a foreign object accidentally falls inside, turn OFF(\circ) ELB immediately, disconnect power cable and contact original dealer of purchase for assistance. Failure to do so may result in fire or electric shock.



Carefully handle test samples following high temperature operation.

Bath and sample/process items are hot during operation and for some time after operation. Be careful with hot items in order to avoid burn injury. Always wear protective equipment when handling test samples during operation or right after operation.



Do not operate unattended.

Do not leave unit unattended during operation of equipment using oil. There is a risk of fire such as ignition of oil smoke.

Implement proper fire extinguishing and ventilation measures.

There is a risk of fire. Implement proper fire extinguishing and ventilation measures. Devices which heat silicon oil present a fire hazard and may emit harmful fumes at 150°C or higher. Always be sure that a ventilation hood is installed over such devices, with a fire extinguisher in close proximity.

Implement proper fire extinguishing and ventilation measures.



Check overheat prevention device.

Confirm that overheat prevention device temperature is set 10 °C above unit temperature setting. Check overheat prevention device performance before extended operations. See "Overheat Prevention Device Setup" (P.19)

6. HANDLING PRECAUTIONS

Warnings and Cautions

DO NOT process corrosive items.

Do not process items containing corrosive chemicals of any kind. Potent acids may corrode the reservoir despite stainless steel construction. Note that acids, alkaline, and halogenated solvents are corrosive to rubber.

0

Wash the bath before use.

The bath has been cleaned at the time of shipment. However, when unit is used for the first time or has been in storage for a long period of time, thoroughly wash the bath before operation.

Supply water and oil with care

Do not overflow the bath or spill water and oil on the unit exterior when adding water. Also, if you accidentally get it on the electrical components such as the operation panel, wipe it off well.

Electrical leakage and/or electric shock may result.



DO NOT operate equipment without water.

This unit employs float switch to prevent unit from running with the bath empty. However, always pay attention to the water level and maintain it at the proper level whenever operating this unit.



ALWAYS run equipment within specified temperature range

Operate unit within the temperature setting range specified in the specifications. Never attempt to operate unit outside of the specified temperature range. Equipment malfunction or accident may result.

Power loss recovery

In the event of a power loss, unit automatically reverts to status just before power loss and begin operation once again from that point. This function may be turned off through Submenu.

If "on" is set and the breaker is turned on (|) after the emergency stop switch is turned on during the fixed operation or after the independent overheating prevention device is activated, the fixed value operation is restored. Confirm the setting before starting an fixed temperature operation.



Overnight and extended storage.

When stopping the device at night or for a long time, turn the breaker "OFF (\circ)".

6. HANDLING PRECAUTIONS

Warnings and Cautions



Use only water and oil for this equipment

Never use it with any liquid other than the specified silicone oil. (Refer to P.17 "About the medium liquid used".)

Periodically change oil and wash the bath container. In particular, impurities adhering to the heater significantly accelerate the deterioration of the heater. Please frequent cleaning.

When used as an aquarium, use ion-exchanged water or distilled water to prevent the accumulation of scale and can stones. Do not use tap water or well water as it not only pollutes the inside of the bath but also reduces the heater efficiency and heater life.



Use calibration offset function to correct temperature reading.

If there is a discrepancy between temperature reading and actual chamber temperature, refer to "Calibration Offset" (P.23) to perform temperature correction.



Inspect regularly.

Circuit breakers and overheating prevention devices are important security devices. Inspect regularly. See "Maintenance and Inspection" (P.64) for detailed instructions.



Using lid

- Ensure that the bath is filled with water or oil before placing the lid on the bath.
- Do not touch the lid other than its handle. The whole lid except the handle becomes hot during high temperature operation.
- When taking off the lid, lift it evenly a little, then slide frontward.
 If you remove it all at once or lift the front side, there is a risk of getting burned by steam.



7. MAINTENANCE PROCEDURES

Precautions before Inspection

- Be sure to disconnect power cable before daily inspection and maintenance.
- Perform inspections and maintenance when unit is at room temperature.
- (Make sure that the water and oil in the bath are below 45 $^\circ$ C.)
- Never attempt to disassemble unit.

Precautions in Daily Maintenance

- Clean unit using soft damp cloth. Never use benzene, paint thinner, scouring powder, scrubbing brush or other abrasives and solvents to clean unit. Superficial damage and/or discoloration, as well as deformity to some components may result.
- Wipe off any dirt in the bath with a dry cloth. Be careful not to damage the heater.

Maintenance and Inspection

- Inspect ELB ON and OFF function.
 Prepare unit for inspection by connecting power cable to a facility outlet or terminal.
 - ≻ Turn ON() ELB.
 - Press the test button on ELB using a ball-point pen or other fine-tipped object. If ELB shuts OFF (o), it is functioning normally.



Check overheat prevention device.

- Set the overheat prevention device temperature 10 °C higher than the unit objective temperature.
- Operate unit in Fixed temperature mode and wait until chamber temperature becomes stable.
- Lower the overheat prevention device temperature by 1 °C.
- If overheat prevention device is functioning normally, heater will shut off within few seconds and error code "Er19" will appear in top display. An alarm will also sound and ALARM lamp will illuminate.
- Check terminals at the cable end for abnormalities
- > Visually check the terminals for dust and dirt. If there is dust or dirt on it, remove it.
- > Visually check the terminals for deformation. Replace if bent or damaged.
- Check the terminals for discoloration or abnormal heat generation. If there is discoloration or abnormal heating, the internal contact of the distribution board may be faulty.

* ELB and overheat prevention device must be inspected, as prescribed above, prior to every instance of extended or overnight operation.

 Contact original dealer of purchase, if further questions arise concerning maintenance procedures.

7. MAINTENANCE PROCEDURES

Maintenance and Inspection

 Please clean the inside of the bath.
 As distillation continues, water in boiler will be concentrated, accelerating the accumulation of boiler scale. When scale build up in the bath, discharge water and clean the bath interior. We recommend using ion-exchanged water or distilled water.When operating with silicone oil, it deteriorates according to the operating temperature / time.
 Replace oil regularly. (Refer to P.17 "About the medium liquid used".)
 Contact original dealer of purchase, if further guestions arise concerning maintenance procedures.

Cleaning the intake filter

- Clean the intake filter.
 - If the operation is continued, dust and dirt will adhere to the intake filter. If it becomes clogged, the performance of the cooling fan inside the housing box will deteriorate. Cleaning intervals will vary depending on usage frequency and operating environment. Be sure to clean condenser fins periodically.
 - Remove the knurled screws on the left and right of the storage box and remove the intake filter from the filter cover.
 - > Remove the dust from the intake filter with a vacuum cleaner, etc., and put it back into unit.



8. EXTENDED STORAGE AND DISPOSAL.

Extended storage

Extended storage	Unit disposal
• Turn OFF (O) ELB and disconnect power	 Do not leave unit in a location where children
cable from facility outlet or terminal.	may have access.
	Contact original dealer of purchase if there are
	any questions.

Disposal Considerations

Dispose of this unit in accordance with local laws and regulations. Dispose of or recycle this unit in a responsible and environmentally friendly manner.

Yamato Scientific Co., Ltd. strongly recommends disassembling unit, as far as is possible, in order to separate parts and recycle them in contribution to preserving the global environment. Major components and materials, comprising this unit are listed in the table below.

Component Name	Material
Main Unit Components	
Exterior	Chromium-free electrogalvanized steel sheet, baked-on finish
Chamber interior	Stainless steel sheet metal
Heat insulator	Gypsum board, ceramic fiber
Rubber legs	Chloroprene rubber
Electrical Parts	
Switches and relays	Composite of resin, copper and other materials
Motor	Composite of steel plate, copper wire, resin coated wiring materials and other compounds
Circuit boards	Boards: epoxy resin, fiber glass Boards are equipped with capacitors, resistors, transformers, etc.
Tube heater	Stainless steel SUS316, nichrome and other composites
Power cable	Composite of synthesized rubber coating, copper, nickel and other compounds
Wiring material	Composites of fiber glass, fire-retardant vinyl, copper, nickel and other compounds
Seals	Resin material
Sensor	Stainless steel etc.

9. TROUBLESHOOTING

Reading Error Codes

Unit has a self-diagnostic function built into the CPU board. The table below shows possible causes when safety function is triggered. If unit does not reset by turning OFF (\bigcirc) and ON (|) ELB, contact original dealer of purchase.

[Error Codes]

When an operational error or malfunction occurs, ALARM lamp on the control panel illuminates, an error code is displayed, and an alarm sounds. Press any key to stop the alarm.

When an error occurs, confirm the error code and terminate operation immediately. For abnormal temperature reading, the controller shows only "----" on display (no lamps go on, and no alarm sounds).

Safety functions	Symptom	Possible causes
Sensor failure	ALARM lamp ON	 Failure in temperature input circuit of the controller Temperature control sensor disconnection/short circuit
SSR short circuit	ALARM lamp ON E - 02 on screen	 Short circuit in SSR
Heater line disconnection	ALARM lamp ON E - 03 on screen	 Heater interruption or disconnection Current sensing element failure, disconnection Drop in power supply voltage
Main relay Main relay contact short circuit	ALARM lamp ON	 Main relay contact short circuit
Memory error	ALARM lamp ON	 Error in CPU storage setting on the controller.
Internal communication error	ALARM lamp ON	 Internal communication error, temperature input circuit failure
Overheating	ALARM lamp ON	 Turn off the ELB for which the overheat protection device is not set properly, and then turn it back on. Check both bath temperature and temperature setting for overheat prevention. If unit does not reset, it may be a result from sensor disconnection. Temperature sensor for overheat prevention is interrupted or disconnected Failure in temperature input circuit of the controller
Abnormal water	ALARM Jamp ON	Water level is insufficient or rising
		See P 18
	screen	 Float switch failure
Abnormal temperature reading	on screen	 Temperature reading is out of display range (-110 to 310 °C)
9. TROUBLESHOOTING

Troubleshooting Guide

Troubles

Symptom	Possible causes		
Unit does not turn on when	• Power cable is not connected securely to power terminal or		
main power switch is turned	outlet.		
"ON"	Power failure in progress		
	 No power from power supply, or supply voltage is low. 		
Temperature does not rise.	 Temperature setting is inappropriate 		
	 Power supply voltage has dropped 		
	• The ambient temperature is out of operable temperature range		
	Operating ambient temperature range for this unit is between		
	5 °C and 35 °C		
	 The amount of test samples is excessive 		
Temperature fluctuates	 Temperature setting is inappropriate 		
during operation	 Power supply voltage is unstable 		
	 The ambient temperature is heavily fluctuating 		
Temperature reading differs	 Calibration offset value is inappropriate. 		
from manually measured	P.23 ·Using calibration offset		
temperature	Check the set value.		

• If none of the above applies, immediately turn off the breaker of this product to "OFF (\circ)" to see if it is a power supply facility.

Contact original dealer of purchase or Yamato sales office for assistance.

10. SERVICE & REPAIR

Requests for Repair

Warranty card (attached separately)

Warranty card will be handed by dealer or Yamato personnel upon delivery and installation, or will be attached to equipment if no one from dealer or Yamato is to be present at delivery and installation.

Register warranty card at https://www.yamato-net.co.jp/support/warranty.htm https://www.yamato-net.co.jp/support/warranty.htm

• Keep warranty card safe.

Requests for Repair

If abnormalities remain after confirming "Troubleshooting Guide", terminate operation, turn off controller and ELB, and disconnect power cable. Contact original dealer of purchase or Yamato sales

office for assistance.

The following information is required for all repairs.

- product nameModel
 - Refer to warranty card.
- Serial number
- Date (year/month/day) of Delivery
- Description of problem in as much detail as possible
- Repair this equipment for free of charge according to the contents on warranty card. Warranty period is 1 (one) year from date of purchase.
- Consult with original dealer of purchase or Yamato sales office for any repair after warranty ended. Charged repair service of this equipment will be available on customer's request when it can be maintained functional by its repair.

*Be sure to present warranty card to the service representative.

Guaranteed Supply Period for Repair Parts

Guaranteed maximum supply period for repair parts is 7 (seven) years from date of discontinuation for this equipment.

"Repair parts" is defined as components which, when installed, allow for continued equipment operation.

11. SPECIFICATIONS

Model		əl le	BOA201	BOA311	
System		m	Jet agitation		
Operating ambient temperature range		ent nge	5 to 35 °C		
Tem	perature se	tting range	0 to 200 °C	0 to 270 °C	
Performance ※1	Temperature control range		Room temp +10 °C to 200 °C	Room temp +10 °C to 270 °C	
	Temperature control accuracy		± 0.1 °C (at 200 °C Silicone Oil JTM K05)		
	Temperature fluctuation		0.2 °C (at 200 °C Silicone Oil JIS)		
	Temperature distribution accuracy		± 0.2 °C (at 200 °C Silicone Oil JTM K05)		
	Temperature gradient		0.5 °C (at 200 °C Silicone Oil JIS)		
	Temperature rise time		Approx. 120 minutes	Approx. 70 minutes	
Co	Exterior		Chromium-free electrogalvanized steel sheet, baked-on finish		
	Bath		Stainless steel sheet metal		
nfic	Heat insu	lator	Ceramic fiber		
Jura	Heater	Туре	SUS316	pipe heater	
atic		Capacity	2 kW	4.5 kW	
ň	Agitator	Туре	Vertical propeller agita	ation, induction motor	
		Capacity	25 W		
	Temperature control system		PID control by microcomputer		
	Temperature setting system		Digital setting with menu keys and the \blacksquare keys		
	Temperature display system		Temperature reading display: Green 4-digit LED digital display Temperature setting display: Red 4-digit LED digital display		
ې م	Temperature resolution		0.1 °C		
ont	Operatior	1 modes	Fixed value operation (with operation indicator lamp)		
troller	Additional functions		Drain valve / operation indicator lamp / external alarm output terminal / temperature output terminal (with 1-5V, 4-20mA changeover switch) / external communication function (RS485) / calibration offset function / set value lock function / power failure recovery mode selection function		
	Output ter block	rminal	External communication terminal (RS-485), Temperature output terminal (with 4-20mA / 1-5V changeover switch) External alarm output terminal		
Sensor			Platinum sensor Pt100 Ω (for temperature control), type-K thermocouple (for overheat prevention)		

※1 Performance data above based on 23 ±5 °C room temperature, 65%RH ±20% humidity, and no process load.

Temperature control accuracy, temperature fluctuation, temperature distribution accuracy, and temperature gradient are the values measured using Toshiba Silicone TSF485-50.

Performance varies depending on the environmental temperature, the type of medium (water, silicone oil) used, and the operating temperature.

11. SPECIFICATIONS

Model		BOA201	BOA311		
Safety devices		Self-diagnostic functions (Automatic overheat prevention, Temperature sensor failure, Heater disconnection, SSR short circuit,main relay failure, memory error, internal communication error, abnormal temperature reading,Abnormal water level), overcurrent leakage breaker, overheating protector, independent overheating preventer, Emergency stop button			
	External dimensions 涨2 (W × D × H) mm	531 x 520 x 578 (height in the bath: 397)			
Standard	Inner bath dimensions ※2 (W × D × H) mm	312 x 440 x 320			
	Effective inner bath dimensions (W × D × H) mm	296 x 340 x 270 (height when the lowest shelf board is installed from the upper edge in the bath)			
	Bath capacity	Approximately 37L (when the amount of oil is up to 50mm from the upper edge of the bath)			
	Effective bath capacity	Approximately 31.9L (when the bottom shelf board is installed)			
	Power supply (50/60 Hz) ※3 Rated current (ELB capacity)	AC115V 18.5A (30A) AC220V 10A (15A)	AC220V 21A (30A)		
	Approx. weight	37 kg			
Accessories		Chamber rack, lid, Instruction manual, Warranty card			
Optional		External communication adapter (RS485-USB conversion) Product code: 281146 Model: OA017			

%2 Dimensions do not include protrusions.

X3 BOA311 with external transformer

·For product improvement, above specifications are subject to change without notice.

12. LIST OF HAZARDOUS SUBSTANCES



Never attempt to process explosives, flammables or any items which contain explosives or flammables.

	Table 13.1 List of hazardous substances
(0	Trinitrobenzen, Trinitrotoluene, Picric Acid and other explosive nitro compounds
Explosive substances	②Trinitrobenzen, Trinitrotoluene, Picric Acid and other explosive nitro compounds
	③Acetyl Hydroperoxide, Methyl Ethyl Ketone Peroxide, Benzoyl Peroxide and other organic peroxides
	Metallic Azide, including Sodium Azide, etc.
Combustible substances	 Metal "lithium" (2) metal "potassium" (3) metal "sodium" (4) yellow phosphorus (5) phosphorus sulfide (6) red phosphorus (7) celluloids (8) calcium carbide (aka ka -baid) (9) phosphorized lime (10) magnesium powder (11) aluminum powder (12) metal powder other than magnesium powder and aluminum powder (13) Sodium subthionate (also known as hydrosulfite)
Oxidizin	①Potassium Chlorate, Sodium Chlorate, Ammonium Chlorate, and other chlorates
	②Potassium Perchlorate, Sodium Perchlorate, Ammonium Perchlorate, and other perchlorates
g St	③Potassium Peroxide, Sodium Peroxide, Barium Peroxide, and other inorganic peroxides
ıbst	④Potassium Nitrate, Sodium Nitrate, Ammonium Nitrate, and other nitrates
anc	⑤Sodium Chlorite and other chlorites
ës	©Calcium Hypochlorite and other hypochlorites
Flammable Substances	①Ethyl Ether, Gasoline, Acetaldehyde, Propylene Chloride, Carbon Disulfide, and other substances with ignition point at 30 or more degrees below zero.
	②n-hexane, Ethylene Oxide, Acetone, Benzene, Methyl Ethyl Ketone and other substances with ignition point between 30 degrees below zero and less than zero.
	③Methanol, Ethanol, Xylene, Pentyl n-acetate, (a.k.a.amyl n-acetate) and other substances with ignition point between zero and less than 30 degrees.
	④Kerosene, Light Oil, Terebinth Oil, Isopenthyl Alcohol(a.k.a. Isoamyl Alcohol), Acetic Acid and other substances with ignition point between 30 degrees and less than 65 degrees.
Combustible gas	hydrogen, acetylene, ethylene, methane, ethane, propane, butane and other flammable objects that are gases at 1 atm and 1 atm

Excerpt from Table 1, Hazardous Substances, of Cabinet Order of the Occupational Safety and Health Law (substances related to Articles 1, 6, and 9)

13. STANDARD INSTALLATION MANUAL

※ Please install according to the following items. (Please check separately for options and special specifications)

Model	Serial number	Installation Date	Charged Personnel or Company Name for Installation	Installation proved by	Judgment

N⁰	Item	Implementation method	Chapter No. & Reference page of instruction manual		Judg ment	
Spe	Specifications					
1	Accessori es	Quantity check according to the accessories column	11. SPECIFICATIONS	P.70		
2	Installatio n	-Securing a space -Visual check of surrounding conditions Note: Pay attention to the surrounding environment, exhaust system, ventilation system, fire extinguisher, type of oil used, and amount of refueling.	3. PRE-OPERATION PROCEDURES -Choose an appropriate -Implement proper 4. PRE-OPERATIVE PREPARATIONS	P.12 P.14 P.17-18		
Ope	eration-related	d matters	1		1	
1	Power supply voltage	Customer voltage with tester Measure (power supply equipment) -Measure line voltage during operation (must meet required	1. SAFETY PRECAUTIONS -Ground wire MUST be 3. PRE-OPERATION PROCEDURES	P.3 P.13		
		voltage) Caution:Use a compliant device to install on a plug or an ELB.	-Always connect power cable to 11. SPECIFICATIONS -Standard-Power Supply	P.70		
2	Starting operation	-Start operation Lubricate with silicone oil, set to 100 ° C and check the stable condition.	3. PRE-OPERATION PROCEDURES -4. PRE-OPERATIVE PREPARATIONS 5. OPERATION PROCEDURES -Operation procedure	P.12-19 P.20-60		
Des	cription					
1	Operation al descriptio ns	Explain about maintenance of equipment and each component according to instruction manual.	5. OPERATION PROCEDURES -Operation procedure 1. SAFETY PRECAUTIONS -12. LIST OF HAZARDOUS SUBSTANCES	P.20-60 P.1-72		
2	error code	To customers according to instruction manual Error code explanation / cancellation method	9. TROUBLESHOOTING -10. SERVICE & REPAIR	P.67-69		
3	Maintenan ce and Inspection	Explain about maintenance of equipment and each component according to instruction manual.	7. MAINTENANCE PROCEDURES -Inspection and Maintenance	P.64		
4	Completio n of installatio n Matters to be Stated	 Enter the date of installation and name of the charged personnel in the main unit nameplate Write necessary information on warranty card and hand it over to customer Explain how to contact service personnel 	10. SERVICE & REPAIR	P.69		

Limited Liability

Always operate equipment in strict compliance to the handling and operation procedures set forth by this instruction manual.

In the unlikely event that it is used with contents other than those described in the instruction manual, an accident or failure may occur.

Never attempt to disassemble, repair or perform any procedure which are not expressly mandated by this manual.

Doing so may result in equipment malfunction, serious personal injury or death.

Notice

• Instruction manual descriptions and specifications are subject to change without notice.

• Yamato Scientific Co., Ltd. will replace flawed instruction manuals (pages missing, pages out of order, etc.) upon request.

Instruction Manual Oil Bath (Large Capacity) BOA201/311 First Edition: January 11, 2022

> Yamato Scientific Co., Ltd. Harumi Triton Square Office Tower Y (36F) 1-8-11 Harumi, Chuo-ku, Tokyo 104-6136, JAPAN

For repair service, maintenance service and consumables purchase support, please contact to our distributors from whom you purchased.

Or please visit to our customer support website at https://www.yamato-scientific.com/support/inquiry/

Yamato Scientific America Inc. 925 Walsh Avenue Santa Clara, CA 95050, U.S.A http://www.yamato-usa.com Toll Free: 1-800-2-YAMATO (1-800-292-6286)