

Error 14 on the Hi-Tec IV CR2 controller

1)Get into the maintenance mode:

Hold down the MODE and PROGRAM keys while simultaneously turning on the main power switch to access the maintenance menu.

2)Select "System Reset":

Rotate the jog dial until "system reset" is displayed.

Press the jog dial.

4)Select mode:

Rotate jog dial to display "yes".

5)Press jog dial:

Press jog dial to select "yes", reset the system and reboot to normal operating mode.

Note:

If this "System Reset" does not solve the error 14, then the HiTec IV cr2 controller will be needed to replace.